

CREEKSIDE 2.0 COLLECTION

THANK YOU FOR YOUR PURCHASE



WARNING DANGER

Failure to follow these warnings and assembly instructions could result in serious injury or death. To help prevent serious or fatal injuries from entrapment or falls:

- Read all instructions before assembling bunk bed and keep these instructions for future reference.
- Before each usage or assembly, inspect bunk bed for damaged hardware, loose joints, missing parts, or sharp edges. DO NOT Use bunk bed if any parts are missing or broken.
- DO NOT Use substitute parts. Contact your local Rooms To Go or visit www.ROOMSTOGO.COM for replacement parts and instructional literature if needed.
- Follow the information on the warnings appearing on the upper bunk end structure and on the carton, DO NOT REMOVE WARNING LABEL FROM BED.
- Always use the recommended size mattress or mattress supports, or both to help prevent the likelihood of entrapment or falls.
- Ensure thickness of mattress and foundation combine does not exceed 10 inches (255mm) and

mattress surface is at least 5 inches (127mm) below upper edge of guardrails.

- Do not allow children under 6 years of age to use the upper bunk.
- Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- Do not allow horseplay on or under the bed and prohibit jumping on the bed.
- Limit top bunk use to one person.
- Always use the ladder for entering and leaving the upper bunk.
- Use of night light may provide added safety precaution for a child using the upper bunk.
- Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- The use of water or sleep flotation mattress is prohibited.
- This bunk bed meets all the requirements of ASTM 1427-19.




STRANGULATION HAZARD:


Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

PARTS LIST

							1
		C C C C C C C C C C C C C C C C C C C		V I	3574 3674 3614 3614 3644 3800 3624 RTG 3574 3574 3674 3604 3614 3604 3614 3624	SKU # ST 0403 400 0403 400 0403 400 0400 400 0400 400 0400 400 0402 400 0402 400 0404 400 0404 400 0404 400 0415 400 0415 400 0416 400 0416 400 0416 400	 3-705 TWIN LOFT END 3-705 TWIN LOFT END 3-705 TWIN LOFT END 3-711 LOFT CHEST 3-711 LOFT DESK 3-711 LOFT DESK 3-721 LADDER 0-645 TWIN SLAT PACK (4) 3-601 FOLDING DESK (Add on) 7 TWIN LOFT WCHEST & DESK CHESTNUT YLE # ITEM DESCRIPTION 3-705 TWIN LOFT END 3-705 TWIN LOFT END 3-710 LOFT CHEST 3-711 LOFT CHEST 3-710 LOFT DESK 3-711 LOFT CHEST 3-710 LOFT DESK 3-711 LOFT CHEST 3-710 LOFT DESK 3-711 LOFT DESK 3-711 LOFT CHEST 3-645 TWIN SLAT PACK (4) 3-601 FOLDING DESK (Add on)
	*****						ot support a mattress alone,
		PARTS LIST					TOOLS NEEDED
PARTS LIST	<u> ΥΤ</u> Ω		QTY	НАГ		QTY	Phillips screwdriver (not included)
1 Twin top bunk bed end	2 Pc	5	1 Pc	A	5/16"-18 x 3 3/8" Bolt	16 Pcs	Allen wrench (included)
	2 Pc -	Loft chest		В	5 mm Hex key	1 Pc	
Side rails				С	6 x 1 1/4" Drywall screw	8 Pcs	FOLDING DESK HARDWARE 0 <td< th=""></td<>
3 Guardrails	2 Pc	6 Loft desk	1 Pc	D	3/8" x 3 1/8" Metal pin	4 Pcs	Drywall screw
4	4 Pc	7	1 Pc	E	()mmmm 1" Screws	6 Pcs	
Twin slats		Folding desk (Add on)		F	0	2 Pcs	
		8	1 Pc		Ladder Hook		



ASSEMBLY INSTRUCTIONS



Use only correct mattress dimensions and Bunkie board:

Twin size mattress- 74" - 75" long and 37-1/2" - 38-1/2" wide Twin size Bunkie board- 74" long and 37-1/2" wide Full size mattress- 74" - 75" long and 52-1/2" - 53-1/2" wide Full size Bunkie board- 74" long and 52-1/2" wide

PLEASE CONTACT YOUR RETAIL STORE WITH SERVICE OR PARTS REPLACEMENT REQUEST

ASSEMBLY INSTRUCTIONS

