



ASHTON AVENUE

DRAWER HUTCH WITH LED LIGHT & DU

DRAWER HUTCH WITH LED LIGHT & DU
DRESSER WITH POWER STRIP



DRAWER HUTCH WITH LED LIGHT & DU
PEDESTAL DESK



COOKIES & CREAM

RTG SKU	STYLE #	ITEM DESCRIPTION
37434521	3452 - 15	Drawer Hutch with Power Led Light & DU
34134522	3452 - 10	Dresser With Power Strip

COOKIES & CREAM

RTG SKU	STYLE #	ITEM DESCRIPTION
37434521	3452 - 15	Drawer Hutch with Power Led Light & DU
34434528	3452 - 14	Pedestal Desk

CHOCOLATE

RTG SKU	STYLE #	ITEM DESCRIPTION
37434533	3453 - 15	Drawer Hutch with Power Led Light & DU
34134534	3453 - 10	Dresser With Power Strip

CHOCOLATE

RTG SKU	STYLE #	ITEM DESCRIPTION
37434533	3453 - 15	Drawer Hutch with Power Led Light & DU
34434530	3453 - 14	Pedestal Desk


This product is manufactured by PTIN for **ROOMS TO GO** | **KIDS**

DO NOT USE SUBTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the Hardware List below. Read all instructions before assembling and keep these instructions for future reference.

CODE	DRAWER HUTCH PART LIST		QTY
A		Drawer Hutch with Power Led Light & DU	1 Pc
B		Drawer Hutch Bracket	2 Pcs


CODE	DRESSER PART LIST		QTY
C		Dresser With Power Strip	1 Pc

CODE	DESK PART LIST		QTY
D		Pedestal Desk	1 Pc

CODE	HARDWARE LIST		QTY
1	JCBC M6 x 1 x 30mm		10 Pcs
2	Lock Washer 11 x 6.5 T=2mm		10 Pcs
3	Flat Washer 16 x 6.5 T=1mm		10 Pcs
4	Allen Key 4mm		1 Pc
Screwdriver (not included)			

HARDWARE PACK LOCATION

RTG SKU	STYLE #	ITEM DESCRIPTION
37434521	3452 - 15	Drawer Hutch with Power Led Light & DU
37434533	3453 - 15	Drawer Hutch with Power Led Light & DU





This product is manufactured by PTIN for **ROOMS TO GO** | **KIDS**

DO NOT USE SUBTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the Hardware List below. Read all instructions before assembling and keep these instructions for future reference.

ASSEMBLY INSTRUCTION



This product is manufactured by PTIN for **ROOMS TO GO** | **KIDS**


DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the Hardware List below. Read all instructions before assembling and keep these instructions for future reference.

HOW TO ASSEMBLY SLIDING DOOR TO DRAWER HUTCH


How to remove sliding door :

Use your point finger to press the buttons and full it down at latches, so the buttons at latches unlock and then remove the door.



How to assembling sliding door :

Press the buttons on latches with forefinger and hold if the door frame already placed on bottom rail, then release the button on latches.



This product is manufactured by PTIN for **ROOMS TO GO** | **KIDS**

DO NOT USE SUBTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST


ROOMS TO GO | KIDS™

DIAGRAM ELECTRICAL SYSTEM

INTEGRA 3452-15 : DRAWER HUTCH WITH LED LIGHT & DU # SKU 37434521
INTEGRA 3453-15 : DRAWER HUTCH WITH LED LIGHT & DU # SKU 37434533



12V/2A
MODEL NO. GFDA5-1202000C



WARNING

El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA

12V/2A
MODEL NO.: GFDA5 1202000C

Leer todas las instrucciones antes de usar este mobiliario.

PELIGRO - Para reducir el riesgo de descarga eléctrica :

1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

ADVERTENCIA : para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas :

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
3. Mantenga el cable eléctrico y el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
6. No fuerce ni estire el cable eléctrico.
7. No utilice cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete.
9. Enchufelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores.

WARNING

Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK

12V/2A
MODEL NO.: GFDA5 1202000C

Read all instructions before using this furnishing.

DANGER - To reduce the risk of electric shock :

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons :

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect, turn all controls to the off position, then remove plug from outlet.
5. When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children. This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters.