




# SCHOOLHOUSE

## CHAIR



| SKU      | STYLE NO. | FINISH     | ITEM DESCRIPTION |
|----------|-----------|------------|------------------|
| 38206579 | 6570-5    | WHITE      | CHAIR            |
| 38226571 | 6572-5    | PINK       | CHAIR            |
| 38236572 | 6573-5    | LIGHT BLUE | CHAIR            |

| CHAIR PARTS LIST |                  |                                                                                     |     |
|------------------|------------------|-------------------------------------------------------------------------------------|-----|
| NO.              | ITEM DESCRIPTION | IMAGE                                                                               | QTY |
| A                | CHAIR BACK       |  | 1pc |
| B                | CHAIR SEAT       |  | 1pc |
| C                | RIGHT FRONT LEG  |  | 1pc |
| D                | LEFT FRONT LEG   |  | 1pc |
| E                | RIGHT STRETCHER  |  | 1pc |
| F                | LEFT STRETCHER   |  | 1pc |
| G                | MIDDLE STRETCHER |  | 1pc |






DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.


**This product is manufactured by (MIYO) for ROOM TO GO® KIDS**

# SCHOOLHOUSE

## CHAIR


| CHAIR HARDWARE LIST |                               |                                                                                    |      |
|---------------------|-------------------------------|------------------------------------------------------------------------------------|------|
| NO.                 | ITEM DESCRIPTION              | IMAGE                                                                              | QTY  |
| 1                   | JCBC Bolt<br>1/4"*20*2-3/4"   |   | 8pcs |
|                     | Lock washer<br>1/4"           |                                                                                    |      |
|                     | Flat washer<br>1/4"x19mm*2mm  |                                                                                    |      |
| 2                   | JCBC Bolt<br>5/16"*18*1-1/2"  |   | 1pc  |
|                     | Lock washer<br>5/16"          |                                                                                    |      |
|                     | Flat washer<br>5/16"x19mm*2mm |                                                                                    |      |
| 3                   | Screw #4*38mm                 |   | 6pcs |
| 4                   | Allen Wrench 4mm              |  | 1pc  |

\*\* SCREWDRIVER(NOT PROVIDED)



**Hardware Pack Location:**

| SKU      | STYLE NO. | FINISH     | ITEM DESCRIPTION |
|----------|-----------|------------|------------------|
| 38206579 | 6570-5    | WHITE      | CHAIR            |
| 38226571 | 6572-5    | PINK       | CHAIR            |
| 38236572 | 6573-5    | LIGHT BLUE | CHAIR            |



CHAIR

Hardware pack is inside of Box Seat  
With Seat (part B)

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM)  
WITH SERVICE OR PARTS REPLACEMENT REQUEST.

**This product is manufactured by (MIYO) for ROOM TO GO® KIDS**


# SCHOOLHOUSE

## CHAIR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list. Read all instructions before assembling furniture and keep these instructions for future reference.


### Assembly Instructions:

#### STEP 1:



Attach the Chair Seat (B) to the Chair Back(A) using Bolts (1),(2), Lock washers and Flat washers with the Allen wrench(4). Do not fully tighten bolts until all parts are assembled.

#### STEP 2:



Attach the Right Stretcher(E) to the Right Front Leg (C) using Bolts (1) Lock washers and Flat washers with the Allen wrench(4). Do not fully tighten bolts until all parts are assembled.

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.

**This product is manufactured by (MIYO) for ROOM TO GO® KIDS**


# SCHOOLHOUSE

## CHAIR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list. Read all instructions before assembling furniture and keep these instructions for future reference.


### Assembly Instructions:

STEP 3:



Attach the Left Stretcher(F) to the Left Front Leg (D) using Bolts (1) Lock washers and Flat washers with the Allen wrench(4). Tighten all bolts using the Allen wrench(4).

STEP 4:



Use screws (3) with a screwdriver (not provided) to secure the stretchers.

DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.

**This product is manufactured by (MIYO) for ROOM TO GO® KIDS**


# SCHOOLHOUSE

## CHAIR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list. Read all instructions before assembling furniture and keep these instructions for future reference.

### Assembly Instructions:

COMPLETED



DO NOT USE SUBSTITUTE PARTS. PLEASE CONTACT YOUR RETAIL STORE OR [WWW.ROOMSTOGO.COM](http://WWW.ROOMSTOGO.COM) WITH SERVICE OR PARTS REPLACEMENT REQUEST.

**This product is manufactured by (MIYO) for ROOM TO GO® KIDS**

# CARING FOR YOUR FURNITURE

- **Protect your investment**

- The beauty of furniture care is that it helps to protect your investment, as fine furniture is an important purchase.
- Proper care will help maintain your furniture's finish and ensure that it looks great year after year.

- **Caring for furniture**

- Caring furniture is easy. Following a few simple guidelines will help extend the life of your furniture.
- Always dust with a cloth moistened with polish. Apply polish to the cloth to protect the surface, eliminating the scratching that occurs when dry dusting. Dust will scratch furniture if not removed quickly. Use a soft, clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics.
- Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood that cause damage to furniture.

- **The Enemies Of Furniture**

- Many common problems in furniture care are caused by the elements. If you are aware of these troublemakers, the resulting damage can easily be avoided.
- Arrange furniture out of direct sunlight. During intense sunlight hours, rotate furniture or adjust room arrangements to minimize exposure.
- Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses and saucers under cups and flowerpots. If a spill occurs, immediately blow it gently without rubbing the surface.
- Heat creates a chemical change in the furniture finish, which can result in a white spot. Use protective mats under hot dishes, utensils, or cooking appliances.
- Cyclic changes in temperature can damage furniture. Placing furniture near a central heating radiator and air duct should be avoided because this causes extreme localized drying of the wood.

- **Tips For Better Dusting**

- Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchangeable.
- Always use a fine furniture polish when dusting. Never dry dust as it could cause scratches on your furniture's surface. Remember to change dusting cloths frequently since a dirty cloth may scratch your furniture's surface.
- Spray your furniture surface evenly but not too generously. Wipe in a circular motion with a soft clean cloth.
- Then buff until completely dry for a beautiful shine and smudge free finish. For wood trim, spray polish on the cloth first, then dust.