

ORACLE

Pedestal Gaming Chair



RTG SKU#	STYLE NO	COLOR	ITEM DESCRIPTION
38230378	30375-BKGD	Black	Pedestal Gaming Chair

DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS


NOTES:

- Please read the instruction sheets completely before assembly.
- Remove all parts from carton and ensure all parts are included prior to assembly.
- Assemble the chair on the carton or carpet to prevent scratching the chair.
- Be careful not to cross-thread bolts.
- Do not stand on the seat cushion.
- Do not allow children to play on or near this product.
- For indoor use only. Please do not expose to direct sunlight, sources of excessive heat, or use in wet or damp environments.
- Only a damp cloth should be used to clean the upholstery surface. For persistent stains and overall cleaning, contact a professional upholstery cleaning company.
- Light-colored upholstery is prone to color transfer from certain clothing and other materials, such as denim jeans. Promptly treat any color transfer with mixture of mild soap and water, avoiding contact with harsh chemicals. Never use cleaners containing alcohol or bleach. Spot-test cleaners on an inconspicuous area before applying to visible surfaces.
- The feet or base of this upholstered item are designed specifically for use on carpeted floors. Using this product directly on tile, hardwood, or laminate flooring may cause damage to those surfaces. To help prevent potential floor damage, please place the item on a carpeted area or use appropriate protective pads..
- Do not use power tools. Only use the allen key provided. Check and re-tighten bolts every 90 days.


DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS


Parts List




Base
Quantity: 1




Central Post
Quantity: 1



Seat Plate
Quantity: 1




Left Arm
Quantity: 1



Right Arm
Quantity: 1



Seat Cushion
Quantity: 1



Back Cushion
Quantity: 1

DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS

Hardware List



Bolts with Washers
Size: M8 X 1.25mm X 70mm
 Quantity: 6



Knobs with Flat Washers
Size: M8 X 1.25mm X 60mm
 Quantity: 2



Bolts
Size: M8 X 1.25mm X 44mm
 Quantity: 4




Allen Key
Size: ø5mm
 Quantity: 1

Hardware Pack Locations

RTG SKU#	STYLE NO	COLOR	ITEM DESCRIPTION
38230378	30375-BKGD	Black	Pedestal Gaming Chair



**Note: Do not use power tools.
 Only use the allen key provided.**




DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS

Step 1

Select a smooth surface to avoid scratching the parts. Match the left arm with the corresponding label on the left side of the seat cushion. Place the Left Arm (D1) on the floor and open the hook and loop under the Seat Cushion (E) to align the holes. Attach 60mm Knob with Flat Washer (H) and 70mm Bolt with Washers (G) using the Allen Key (J).

Note: Install the knob **before** the bolt for easier assembly. Do not tighten them completely.





DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS

Step 2

Open the zipper on the Back Cushion (F) as shown. Align the Back Cushion (F) with the Left Arm (D1) and attach it using 70mm Bolts with Washers (G) with Allen Key (J).

Note: Do not tighten bolts completely.






DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS

Step 3

Align the Right Arm (D2) with the Seat Cushion (E) and Back Cushion (F). Secure the Right Arm (D2) using 60mm Knob with Flat Washer (H) and 70mm Bolts with Washers (G) with Allen Key (J). Once all parts are aligned and connected, go back and fully tighten all the bolts and knobs. Close the zipper on the Back Cushion (F) and attach the hook and loop to the Seat Cushion (E).
Note: Install the knob before the bolts for easier assembly. Tighten the knobs and bolts completely.



ATTENTION: To close the zipper, please follow diagram 2. Failure to follow this could result in damage to the zipper.


DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS

Step 4

Attach Seat Plate (C) to the bottom of the Seat Cushion (E), with the front of the seat plate facing the front of seat cushion. (For reference, the large tension knob is near the front of the seat plate.) Attach by using 44mm Bolts (I) for the holes of the Seat Plate (C) and tighten bolts.

Note: Tighten the bolts completely.




DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS

Step 5

Insert the Central Post (B) through the center hole on top of the Base (A). Insert the Central Post (B) into the center hole of the Seat Plate (C) located behind the tension knob. Lift the chair upright and push down firmly until the Central Post (B) is securely connected to the Seat Plate (C).



DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS


Operating Instructions

Function Instruction - 1

To Operate Tilt Lockout:

While seated, reach under the right side of the chair to find the handle. Pull the handle all the way out to allow the chair to tilt backward. Push the handle in towards the central post to lock the chair angle at the normal position or a larger tilt angle. When you want to release the mechanism from the locked position, pull the handle all the way out, apply additional weight backward onto the back cushion, and then release. The back cushion will return to its normal position.

Note: It has 2 locking positions.



Function Instruction - 2

To Adjust Tension on the Tilt

Reach under the front center of chair seat and grasp the round black tension knob. To loosen the tilt mechanism, turn the knob clockwise. This lessens the effort required to rock back and forth. Rotate the knob until desired resistance is reached.




DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM WITH SERVICE OR PARTS REPLACEMENT REQUEST


The product is manufactured by LISI for ROOMS TO GO® | KIDS

Operating Instructions

Function Instruction - 3 Armrest Side Pockets.



Function Instruction - 4 360° Swivel: 360° seat swivel.



DO NOT USE SUBSTITUTE PARTS, PLEASE CONTACT YOUR RETAIL STORE OR WWW.ROOMSTOGO.COM
WITH SERVICE OR PARTS REPLACEMENT REQUEST

The product is manufactured by LISI for ROOMS TO GO® | KIDS