

CREEKSIDE 2.0 COLLECTION

THANK YOU FOR YOUR PURCHASE



WARNING DANGER

Failure to follow these warnings and assembly instructions could result in serious injury or death. To help prevent serious or fatal injuries from entrapment or falls:

- Read all instructions before assembling bunk bed and keep these instructions for future reference.
- Before each usage or assembly, inspect bunk bed for damaged hardware, loose joints, missing parts, or sharp edges. DO NOT Use bunk bed if any parts are missing or broken.
- DO NOT Use substitute parts. Contact your local Rooms To Go or visit www.ROOMSTOGO.COM for replacement parts and instructional literature if needed.
- Follow the information on the warnings appearing on the upper bunk end structure and on the carton, DO NOT REMOVE WARNING LABEL FROM BED.
- Always use the recommended size mattress or mattress supports, or both to help prevent the likelihood of entrapment or falls.
- Ensure thickness of mattress and foundation combine does not exceed **10 inches (255mm)** and mattress surface is at least **5 inches (127mm)** below upper edge of guardrails.
- Do not allow children under 6 years of age to use the upper bunk.
- Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- Do not allow horseplay on or under the bed and prohibit jumping on the bed.
- Limit top bunk use to one person.
- Always use the ladder for entering and leaving the upper bunk.
- Use of night light may provide added safety precaution for a child using the upper bunk.
- Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- The use of water or sleep flotation mattress is prohibited.
- This bunk bed meets all the requirements of ASTM 1427-19.




STRANGULATION HAZARD:

Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

11/7/2022 Page 1 of 97

PARTS LIST



3924040P TWIN/FULL STEP LOFT W/CHEST CHARCOAL							
RTG SKU#	STYLE#	ITEM DESCRIPTION					
35840405	40G-160	STEP STORAGE UNIT					
35740403	40G-705	TWIN LOFT END					
36940408	40G-709	FULL CASTER BED HD & FT					
36640402	40G-730	6 PC RAILS (2 GUARD & 4 SIDE RAILS)					
36040400	40G-711	LOFT CHEST					
37040401	40G-735	TWIN RAIL CAP					
38000232	100-645	TW. SLAT PACK (4)					
38100234	100-646	FULL SLAT PACK (4)					
36240404	40G-601	FOLDING DESK (Add on)					

3924041P TWIN/FULL STEP LOFT W/CHEST CHESTNUT								
RTG SKU#	STYLE#	ITEM DESCRIPTION						
35840417	40B-160	STEP STORAGE UNIT						
35740415	40B-705	TWIN LOFT END						
36940410	40B-709	FULL CASTER BED HD & FT						
36640414	40B-730	6 PC RAILS (2 GUARD & 4 SIDE RAILS)						
36040412	40B-711	LOFT CHEST						
37040413	40B-735	TWIN RAIL CAP						
38000232	100-645	TW. SLAT PACK (4)						
38100234	100-646	FULL SLAT PACK (4)						
36240416	40B-601	FOLDING DESK (Add on)						

The bed slats included with this bed will not support a mattress alone, this bed requires Bunkie boards (sold separately)

QTY

24 Pcs

1 Pc

16 Pcs

2 Pcs

4 Pcs

PARTS LIST		QTY	PARTS LIST		QTY	HARDWARE LIST			
1		1 Pc			1 Pc	A	5/16"-18 x 3 3/8" Bolt		
2	Twin top bunk bed end	4 Pc		Step bunk unit		В	5 mm Hex key		
	Side rails					С	6 x 1 1/4" Drywall screw		
3	Guardrails	2 Pc	8	E Loft chest	1 Pc	D	3/8" x 3 1/8" Metal pin		
4	Twin slats	4 Pc	9	Caster bed headboard	1 Pc	Е	Casters		
5	Full slats	4 Pc	10	Caster bed footboard	1 Pc				
6	Twin rail cup	1 Pc	11	Folding desk (Add on)	1 Pc		TWO P		

FOLDING DESK HARDWARE 2 Pcs 6 x 1 1/4" Drywall screw

TOOLS NEEDED Phillips screwdriver (not included)

Allen wrench (included)


TWO PEOPLE ARE NEEDED TO ASSEMBLE DO NOT TIGHTEN COMPLETELY UNTIL ALL PIECES ARE CONNECTED TOGETHER


11/7/2022 Page 25 of 97


TIPS: SEE ILLUSTRATION BELOW


- 1- Use the long end of the allen wrench to fasten bolts loosely and quickly.
- 2- Use the short end of the allen wrench for final tightening



















Install slats, one on each end, two equally spaced in the middle, then fasten with 1 1/4" screws.

11/7/2022 Page 26 of 97




STEP 5






STEP 6




Install slats, one on each end and two equally spaced in the middle, then fasten with 1 1/4" screws




Page 27 of 97

MAKE SURE ALL BOLTS ARE TIGHTENED COMPLETELY



11/7/2022

Slide Caster bed under Loft bed as shown.




Place Bunkie boards (required, sold separately) on top of the slats

Use only correct mattress dimensions and Bunkie board:


Twin size mattress- 74" - 75" long and 37-1/2" - 38-1/2" wide
Twin size Bunkie board- 74" long and 37-1/2" wide
Full size mattress- 74" - 75" long and 52-1/2" - 53-1/2" wide
Full size Bunkie board- 74" long and 52-1/2" wide

PLEASE CONTACT YOUR RETAIL STORE WITH SERVICE OR PARTS REPLACEMENT REQUEST


11/7/2022 Page 28 of 97




STEP 11




Unfold desk leg and look for hardware pack inside desk box.



Unfold corner supports




Secure each corner block with 1 1/4" screw (from desk box hardware pack) in the pre-bore hole.



Place folding desk by sliding into the opening of loft chest then push down

11/7/2022 Page 29 of 97

STEP 15



Place Bunkie boards (required, sold separately) on top of the slats

Use only correct mattress dimensions and Bunkie board:

Twin size mattress- 74" - 75" long and 37-1/2" - 38-1/2" wide
Twin size Bunkie board- 74" long and 37-1/2" wide
Full size mattress- 74" - 75" long and 52-1/2" - 53-1/2" wide
Full size Bunkie board- 74" long and 52-1/2" wide

PLEASE CONTACT YOUR RETAIL STORE WITH SERVICE OR PARTS REPLACEMENT REQUEST

11/7/2022 Page 30 of 97