

WOODLAND ADVENTURES

Changing Tray

Model: DP-CS-3120CS-ELM
(CS-3120CS)

RTG SKU #: 39831082

Assembly Instruction

This changing tray is designed to be use with RTG SKU - 34131083 (DP-DD-3108LD-ELM) dresser only. Dresser sold separately.



WARNING

FALL HAZARD - Children have suffered serious injuries after falling from changing tables. Falls can happen quickly.

- **STAY** in arm's reach of your child.
- This changing tray is designed to be use with RTG SKU - 34131083 (DP-DD-3108LD-ELM) dresser only. Dresser sold separately.
- **ALWAYS** secure this product to RTG SKU - 34131083 (DP-DD-3108LD-ELM) dresser only by using the hardware provided. See instructions.

SUFFOCATION HAZARD: Babies have suffocated while sleeping in changing area.

Changing area are not designed for safe sleeping.

- **NEVER** allow baby to sleep in changing area.

 **WARNING !** When child reaches a maximum weight of 30 lbs, the changing tray shall no longer be use.

- The changing pad (not included) used should be 16.5" (41.9cm) W x 32.5" (82.55cm) L with a maximum thickness of 1" (2.54cm).
- Read all instructions before use of the changing tray.
- Do not use the changing tray if it is damaged or broken.
- Keep instructions for future use.

Congratulations on your purchase of a Westwood product. We take great pride in the quality and design of our furniture. It is important that you read these instructions carefully and completely to ensure that this product functions as it was designed.


After opening the package, check to see that all the parts are present. If you think something is missing, please contact your retailer, and they can arrange to have the missing parts quickly replaced. You can also contact us directly, by calling 1-908-719-4707, or emailing support@westwoodbaby.com If any aspect of these instructions is unclear, please contact your retailer or Westwood Design for assistance.


WESTWOOD DESIGN


635 N. Billy Mitchell Rd.,
Salt Lake City, UT 84116
Phone: 908-719-4707

www.westwoodbaby.com

Changing Tray (Cabinet not included)




Changing Tray
(x1)



Changing Tray Top Panel
(x1)




JCBC Bolt M6 x 35mm
(x4)




Allen Wrench


Step 1



Changing Tray (Cabinet not included)



Changing Tray
(x1)




Metal plate
(x2)





Screw
(x4)

Tool required



Screwdriver - Not provided

Step 2



Screwdriver - Not provided



CARE AND MAINTENANCE

- After completing assembly, check that all bolts and screws are secure and tight. Hardware can become loose over time, so it is your responsibility to periodically check the tightness of all fasteners for as long as you use the crib.
- Wood is a natural material. As such, it can be affected by changes in temperature and humidity. Extreme changes in humidity and temperature can cause the wood to warp, swell, crack, or shrink, thus compromising the structural integrity of the crib and making it dangerous to use.
- Use caution when placing the crib in storage to avoid extremes in temperature or humidity. Cribs should always be stored indoors in climate controlled, dry locations.
- Use care when using a vaporizer or humidifier around the crib. Do not aim the vapor at the crib or any other wooden furniture in the nursery. Avoid using vaporizers or humidifiers for extended periods of time.
- To clean the crib, wipe with a damp cloth and immediately dry the surface. Do not use any chemical cleaners or polishes. Such products can leave a residue on the finish and come in contact with your child.
- Your crib has a durable and protective non-toxic finish. However, if you decide to refinish it, you must use a non-toxic finish specified for children's products. Do not use any toxic stripping methods to remove the old finish.

WESTWOOD DESIGN

635 N. Billy Mitchell Rd.,
Salt Lake City, UT 84116
Phone: 908-719-4707

www.westwoodbaby.com