



60702 Dining Chair



Estimated Time for Assembly

5:00 - 10:00



Weight Limitation

300 lb

Tools Needed

All necessary tools are included in the package.


PLEASE CONTACT US FOR QUESTIONS


Email our support team: help@ovis.co


- Read all instructions before assembling this product.
- Check this product for damaged hardware, loose joints, missing parts, or sharp edges after assembly and frequently during use.
- Do not use this product if any parts are missing, damaged, or broken.
- Properly discard all packaging materials after assembly is complete.
- This product contains small parts. Keep small parts out of children's reach during assembly.
- This chair is designed to be used by one individual at a time.
- When placing furniture on non-carpeted flooring, we recommend the use of floor protection such as an area rug or furniture pads.
- The maximum weight capacity of this chair is 300 lbs.
- Do not use this chair near fire or water.
- This product has moving parts, serious injuries can occur if not used appropriately.
- Do not sit on the edge of the seat, armrests, or backrest.
- Do not jump on chair.
- Do not use the chair as a step stool.
- Do not leave children unattended on or beside the chair.
- Do not let children play on or near the chair when in use. Serious injury can occur.

PACKAGE CONTENT









FINISH!

FOR ADDITIONAL HELP:

Email our support team: help@ovis.co

THANK YOU FOR PURCHASING!