

ASSEMBLY INSTRUCTION

SKU # 53424



Before beginning:

! Unpack all parts and hardware to ensure you have all needed components for assembly.
 ! Read this guide cover to cover before beginning assembly.
 ! Assembly this item on a soft surface, such as carpet to protect finish.
 ! Proper assembly of this item requires 2 people & 20 minutes to assemble




CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners, Any liquid spilled on the table should be cleaned up immediately with a damp cloth.


PARTS LIST :

No.	Description	Sketch	Quantity
A	Top		1
B	Leg		2


HARDWARE LIST :

No.	Sketch	Description	Size	Quantity
C		Allen Bolt	0.31x0.78	8 + 1
D		Spring Washer	0.35x0.5	8 + 1
E		Washer	0.35x1	8 + 1
F		Allen Key	0.19	1


Step : 1




Step : 2



ADJUSTABLE LEVELERS



step-3



final