



Assembly Instruction


STOF

8905-RD4242W (ST8905-RD4242B) Round Drop Leaf Table
8906-RD4242B (ST8906-RD4242B) Round Drop Leaf Table

SKU# 42089056
SKU# 42089070


Version 1 - 2026/04/07



WARNING: To avoid alignment issue, please don't tighten the screws unless all legs are adjusted at the same level.


Step	Code	HARDWARE LIST	QTY'
	1	Allen Key 5/32" 	1 PC
1	2	Long Bolt 5/16-18 x 3-1/2" (PRE-ASSEMBLED) Spring washer 5/16" (PRE-ASSEMBLED) Flat washer 5/16" (PRE-ASSEMBLED) Threaded washer 5/16" (PRE-ASSEMBLED) 	8 PCS

TOOLS REQUIRED (NOT PROVIDED)

Phillips Screwdriver



Code	PART LIST	QTY'
A	Table Top 	1 PC
B	Legs 	4 PCS



ASSEMBLY COMPLETED

Hardware Pack Location (s):

STOF

8905-RD4242W (ST8905-RD4242B) Round Drop Leaf Table
8906-RD4242B (ST8906-RD4242B) Round Drop Leaf Table

SKU# 42089056
SKU# 42089070

This product is manufactured by STOF

Assembly Instruction

STOF


8905-RD4242W (ST8905-RD4242B) Round Drop Leaf Table
8906-RD4242B (ST8906-RD4242B) Round Drop Leaf Table

SKU# 42089056
SKU# 42089070

Version 1 - 2026/04/07


***Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and insure the parts are not damaged during the assembly.

STEP 1



Turn Table Top upside down on a soft protective surface such as a carpet.
Attach Table Legs to Table Top . Using the provided hardware as shown on.

STEP 2



Assembly Instruction

STOF


8905-RD4242W (ST8905-RD4242B) Round Drop Leaf Table
8906-RD4242B (ST8906-RD4242B) Round Drop Leaf Table

SKU# 42089056
SKU# 42089070


Version 1 - 2026/04/07

***Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and insure the parts are not damaged during the assembly.



STEP 3



STEP 4



To fold the table leaf :
Move the wood bar inward.



To extend the table leaf :
Move the wood bar outward.