





Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

COMPONENT LIST			
NO.	Description	Sketch	Q'TY
A	Table top		1pc
B	Table Leg		2pcs
C	Connector Board		1pc
D	Joint Panel		2pcs

HARDWARE LIST				
NO.	Picture	Description	Dimension	Q'TY
1		Flat Washer	1/4"*16*2mm	4 pcs
		Spring Washer	1/4"*12*2mm	4 pcs
		Bolt	1/4"*20*15mm	4 pcs
2		Allen Key	4mm	1 pc
3		L-Bracket	32*20*16mm	2 pcs
4		Tool Required(not provided)		




Hardware pack locations


5451-835 COUNTER HEIGHT TABLE - SKU : 43154513
 5451-810 DINING TABLE - SKU : 42154512

PARTS DETAILS


STEP 1: Attach the L-Bracket (3) to Table Legs (B), secure with Flat Washers, Spring Washers and Bolts (1) by using Allen Key (2).




STEP 2: Attach the Center Support (C) to Table Legs (B)




STEP 3: Using L-Bracket (3), secure the Center Support (C) to Table Legs (B) using flat washers, spring washers, bolts (1) and Allen key (2).




STEP 4: Attach the Top Support (D) to Table Leg (B) secure with Flat Washers, Spring Washers and Bolts by using Allen Key (2).



STEP 5: Attach the **Table Leg (B)** to **Table top (A)** secure with Flat Washers, Spring Washers and Bolts by using Allen Key (2).



STEP 6:



**Adjustable
Leveler**