



Assembly Instruction


STOF



8905-3660TB (ST8905-3660TB) Leg Table
8906-3660TB (ST8906-3660TB) Leg Table


SKU# 42189058
SKU# 42189072

Version 1 - 2026/04/07

WARNING: To avoid alignment issue, please don't tighten the screws unless all legs are adjusted at the same level.

Step	Code	HARDWARE LIST	QTY'
	1	Allen Key 5/32" 	1 PC
1	2	Long Bolt 5/16-18 x 3-1/2" (PRE-ASSEMBLED) Spring washer 5/16" (PRE-ASSEMBLED) Flat washer 5/16" (PRE-ASSEMBLED) Threaded washer 5/16" (PRE-ASSEMBLED) 	8 PCS

Code	PART LIST	QTY'
A	Table Top 	1 PC
B	Legs 	4 PCS



ASSEMBLY COMPLETED

Hardware Pack Location (s):

STOF

8905-3660TB (ST8905-3660TB) Leg Table
8906-3660TB (ST8906-3660TB) Leg Table

SKU# 42189058
SKU# 42189072

This product is manufactured by STOF

1 OF 2



Assembly Instruction

STOF


8905-3660TB (ST8905-3660TB) Leg Table
8906-3660TB (ST8906-3660TB) Leg Table

SKU# 42189058
SKU# 42189072

Version 1 - 2026/04/07

***Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two people are recommended in order to prevent personal injury and insure the parts are not damaged during the assembly.

STEP 1



Turn Table Top upside down on a soft protective surface such as a carpet.
Attach Table Legs to Table Top . Using the provided hardware as shown on.