ROOMS TO GO ▶

ASSEMBLY INSTRUCTIONS


MODEL: 1038

AXEL

1038-R ROUND DINING TABLE - SKU#42230451

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts. Which may have come loose inside the carton during shipment. Identify and count all parts and compare with the hardware list as below:

Hardware List	No.	Picture	Description	Dimension	Qty
	1		JCBC (M6)	6 x P1.0 x 45mm	2 Pcs
	2	<u> </u>	JCBC (M6)	6 x P1.0 x 35mm	4 Pcs
	3		CSK Screw (M4)	4 x 32mm	16 Pcs
	4		Adjustable Glide (M6)	6 x 20mm	4 Pcs
	5		Allen Wrench (M4)	4 x 60mm	1 Pc
Parts List	No.	Description			Qty
	A	Table Top			1 Pc
	В	Leg			2 Pcs
	C	Mounting Support			2 Pcs
	D	Glass			1 Pc




Assembly Step

STEP 1

Assembly the table leg by JCBC and insert the adjustable as per pic show


STEP 2

Assembly the table support to table leg




STEP 3


Assembly table base to table top



STEP 4

Finally, insert the glass to table top





NOTE:

To ensure that table is level, assemble the table on flat & soft surface. DO NOT tighten all the screws & bolts until the table been adjust & level all the legs so that they do not wobble. Once adjusted then only tighten all the screws