



# ASSEMBLY INSTRUCTIONS

MODEL : 4733-30ST STORAGE DINING TABLE



SKU# 42247331


Manufactured by (AXEL) for Rooms To Go

Version 1 05/2025

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts. Which may have come loose inside the carton during shipment. Identify and count all parts and compare with the hardware list as below :

	No.	Description	Dimension	Picture	Qty
Hardware List	①	Allen Wrench	M4 x 95mm		1 Pc
	②	Rubber Bumper			4 Pcs


	No.	Description	Picture	Qty
Part List	A	Table Top With Storage		1 Pc
	B	Table Leg		4 Pcs



## PARTS DETAILS

### Hardware Pack Location(s) :


STORAGE DINING TABLE,  
SKU# 42247331



## Assembly step


### STEP 1

Assemble LEG to STORAGE TABLE as shown in the illustration.  
DO NOT TIGHTEN THE SCREWS UNTIL FULLY SET UP.



### STEP 2

Place RUBBER BUMPER at the top of LEG as shown.  
Assemble Complete.



#### NOTE:

To ensure that Table is level, assemble the Table on flat & soft surface. DO NOT tighten all the screw & bolts until the Table been adjust & level all the legs so that they do not wobble. Once adjusted then only tighten all the screw using Allen Key while making sure that the unit remain level.