

ASSEMBLY INSTRUCTIONS

ITEM NO : D00507 DC DINING CHAIR

Thank you for purchasing this quality product. Be sure to check all packing material care fully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the HARDWARE LIST below.







HARDWARE / PARTS LOCATION

D00507 DC > Step 1 & 2 & 3 hardware > Inside red pack with red tape > Placed beside seat

> Leg > Inside labeled inner carton > Placed between seat

> Seat Cushion > Placed at bottom.


>Stretcher > Placed at the seat underside

NO.	DESCRIPTION	SKETCH	QTY
A	Chair Back		1PC
B	Seat Frame with Cushion		1PC
C	Left Front Leg		1PC
D	Right Front Leg		1PC
E	Left Side Stretcher		1PC
F	Right Side Stretcher		1PC


NO.	HARDWARE LIST		QTY
1		Bolt (Ø1/4"x75mm)	4Psc
2		Bolt (Ø1/4"x40mm)	2Pcs
3		Nut (Ø5/16"x13mm)	4Pcs
4		Flat Washer (Ø5/16"x19x2mm)	10Pcs
5		Spring Washer (Ø5/16x13x1.5mm)	10Pcs
6		Allen key 4mm	1PC
7		Wood Screw (#4x45mm)	4Pcs
8		Allen Wrench 13mm	1PC

Tool required:
Phillips screwdriver (not provided)


STEP 1



STEP 2



STEP 3



Note: Please DO NOT fully tighten all screws and bolts until the entire item is completely assembled