




ASSEMBLY INSTRUCTIONS

AAMR 620-65 SLATBACK CHAIR - WOOD SEAT

Manufactured by AAMR for Room To Go SKU : 42406202 Version 2: 1/25

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.




HARDWARE LIST				
NO.	Code	Description	Picture	Q'TY
1	A	Allen Key M4 X 2½		1 Pc
2	B	Screw 8 x 1¼		4 Pcs
3	C	Assembly Glue 10g		1 Pc
4	Tool Required (not provided)			

PART LIST	
	1. Back Rest -1 Pc
	2. Wood seat - 1 Pc
	3. Front Leg -R - 1 pc
	4. Front Leg -L - 1 pc
	5. Side Stretcher-R- 1 pc
	6. Side Stretcher-L- 1 pc

Hardware Pack Location (s) :

620-65 SLATBACK CHAIR - WOOD SEAT, SKU #42406202




ASSEMBLY INSTRUCTIONS

AAMR 620-65 SLATBACK CHAIR - WOOD SEAT


Manufactured by AAMR for Room To Go SKU : 42406202 Version 2: 1/25

STEP 1: Attach the Wood Seat (2) to Back Rest (1), secure with Flat Washers, Spring Washers and Bolts by using Allen Key (A). Do not tighten all the bolts until the assembly is completed.

STEP 2: Secure with Flat Washers, Spring Washers and Bolts by using Allen Key (A). Do not tighten all the bolts until the assembly is completed.



STEP 3 : Apply Glue (C) to the pre-drilled holes on the legs. Attach the Front legs- L (3),Side Stretcher L (5) and the Front legs- R (4), Side Stretcher R (6) to Wood Seat (2), and Back Rest (1), secure with Flat Washers, Spring Washers and Bolts by using Allen Key (A) provided. Do not tighten all the bolts until the assembly is completed.



ASSEMBLY INSTRUCTIONS

AAMR 620-65 SLATBACK CHAIR - WOOD SEAT

Manufactured by AAMR for Room To Go SKU : 42406202 Version 2: 1/25

STEP 4 Insert Screw(B) into Side Stretcher-L (5) and Side Stretcher -R(6) through the pre-drilled holes then tighten by using Philip Head Screw Driver (Not provided).

