



Manufactured by PNWD for Rooms To Go

ASSEMBLY INSTRUCTION


PNWD 3230-DC SIDE CHAIR - SKU: 42632326

Version #1 - 2025/06/09

THANK YOU FOR PURCHASING THIS QUALITY PRODUCT. BE SURE TO CHECK ALL PACKING MATERIALS CAREFULLY FOR SMALL HARDWARE WHICH MAY HAVE COME LOOSE INSIDE THE CARTON DURING SHIPMENT. IDENTIFY AND COUNT ALL HARDWARE AND COMPARE WITH THE HARDWARE LIST BELOW.

TOOLS REQUIRED (NOT PROVIDED)


Phillips screwdriver




PARTS LIST :

No.	Description	Sketch	Q'ty
A		Chair Back	1
B		Seat Cushion	1
C		Right Leg	1
D		Left Leg	1
E		Stretcher	2

HARDWARE LIST :

NO.	HARDWARE LIST		Q' TY
1		Ø5/16"X19X2mm Flat washer	9
2		Ø5/16"X12x1mm Spring washer	9
3		Ø5/16"X76mm Long Bolt (18 TPI)	5
4		Ø5/16" X12mmHex Nut	4
5		Ø5/16" Wrench	1
6		4mm Allen wrench	1
7		Ø8 x 32 Screw	4



**Hardware Pack Location: Inside red pack with red tape > Placed at bottom chair frame.
3230-DC SIDE CHAIR - SKU: 42632326**



Manufactured by PNWD for Rooms To Go

ASSEMBLY INSTRUCTION


PNWD 3230-DC SIDE CHAIR - SKU: 42632326

Version #1 - 2025/06/09


THANK YOU FOR PURCHASING THIS QUALITY PRODUCT. BE SURE TO CHECK ALL PACKING MATERIALS CAREFULLY FOR SMALL HARDWARE WHICH MAY HAVE COME LOOSE INSIDE THE CARTON DURING SHIPMENT. IDENTIFY AND COUNT ALL HARDWARE AND COMPARE WITH THE HARDWARE LIST BELOW.

STEP 1


REMARK: DO NOT fully tighten all bolts and screws until assembly completed.



STEP 2



STEP 3



**Hardware Pack Location: Inside red pack with red tape > Placed at bottom chair frame.
3230-DC SIDE CHAIR - SKU: 42632326**

CARING FOR YOUR FURNITURE

- **Protect your investment**

- The beauty of furniture care is that it helps to protect your investment, as fine furniture is an important purchase
- Proper care will help maintain your furniture's finish and ensure that it looks great year after year

- **Caring for furniture**

- Caring furniture is easy. Following a few simple guidelines will help extend the life of your furniture
- Always dust with a cloth moistened with polish. Polish cushions the cloth, eliminating the scratching that occurs with dry dusting. Dust will scratch furniture if not removed quickly. Use a soft clean cloth that won't scratch the surface. Avoid coarse or scratchy materials or fabrics
- Avoid using soap and water on furniture. Water can penetrate the finish and raise the grain on wood that cause damage to furniture.

- **The Enemies Of Furniture**

- Many common problems in furniture care are caused by the elements. If you are aware of these trouble makers the resulting damage can easily be avoided
- Sunlight's ultraviolet rays can damage wood finishes. Arrange furniture out of direct sunlight use sun screening intense sunlight hours rotate furniture in place and room arrangement
- Liquid spills will damage furniture if not removed promptly. Use coasters under beverage glasses and saucers under cups and flowerpots. If a spill occurs. Immediately blow it gently without rubbing the surface.
- Heat creates a chemical change in the furniture finish. Which can result in a white spot. Use protective mats under hot dishes, utensils or cooking appliances
- Cyclic changes in temperature can damage furniture. Placing furniture near to central heating radiator and air duct should be avoided because this causes extreme localized drying of the wood

- **Tips For Better Dusting**

- Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchange
- Always use a fine furniture polish when dusting. Never dry dust as it could cause scratches on your furniture's surface. Remember to change dusting cloths frequently since a dirty cloth may scratch your furniture's surface.
- Spray your furniture surface evenly but not too generously. Wipe in a circular motion with a soft clean cloth.
- Then buff until completely dry for a beautiful shine and smudge free finish. For wood trim spray polish on the cloth first then dust.