



Manufactured by ITCO for Rooms To Go

ASSEMBLY INSTRUCTIONS



ITCO 1816-SVR SERVER WITH POWER STRIP SKU : 42918168

Thank you for purchasing this quality product . Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment .Identify and count all parts and compare with the hardware list as below :

	No.	Picture	Description	Dimension	Qty
Hardware list	①		Allen Key (M4)	4 x 58mm	1 Pc
	②		Anti-Tipping Hardware		1Set
	No.	Description			Qty
Parts list	A	Server			1 Pc
	B	STRETCHER			1 Pc
	C	Legs			2 Pcs

TOOLS REQUIRED (NOT PROVIDED)

Phillips Screwdriver



PARTS DETAIL


Hardware Pack Location (s): Underneath server bottom

SERVER WITH POWER STRIP SKU : 42918168

Version 1 - date created : 12-2024

Assembly Steps


STEP 1



Hardware is pre-attached

Hardware is pre-attached

STEP 2



Hardware is pre-attached


NOTE :

To ensure that the unit is levelled, assemble the unit on flat & soft surface. DO NOT tighten all the screws & bolts until the unit been adjust & level all the legs so that they do not wobble. Once adjusted then only tighten all the screws using Allen Key while making sure the unit remain level.

Assembly Steps

STEP 3

REMARK:
Anti-tip hardware - customer assembly required.



If you prefer to adjust the shelf location, remove the screws and move shelf brackets to the desired location. Then secure the brackets to shelf with screws.

IMPORTANT SAFETY INSTRUCTIONS

WARNING

Misuse can result in FIRE or DEATH by ELECTRICAL SHOCK
ELECTRICAL RATING (120VAC / 12AMPERES)
DONGGUAN GLORY LIGHTING CO.,LTD
PART NUMBER (HG2000-DNU2)

Read all Instructions before using this furnishing.

DANGER –To reduce the risk of electric shock

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Never operate this furnishing if it has a damaged electrical cord or plug, if it is not working properly, or if the electrical cord or plug has been damaged or dropped into water. Stop using this furnishing and call a service center for examination and repair.
3. Keep the electrical cord and plug away from heated surfaces and other heat sources.
4. To disconnect, turn all controls to the off position, then remove plug from outlet.
5. When operating, ensure that electrical cord is not under the base, legs, or motion mechanism to avoid damage to electrical cord or plug.
6. Do not strain or stretch electrical cord.
7. Do not use extension cords or power strips.
8. Keep out of reach of children. This is not a toy.
9. Plug directly into a compatible electrical socket.
10. Do not modify the plug or use any adapters.

INSTRUCCIONES DE SEGURIDAD IMPORTANTES

WARNING

El mal uso puede provocar INCENDIO o MUERTE por DESCARGA ELÉCTRICA
CLASIFICACION ELECTTRICA (120VAC/ 12AMPERES)
DONGGUAN GLORY LIGHTING CO.,LTD
PART NUMBER(HG2000-DNU2)

Leer todas las Instrucciones antes de usar este mobiliario.

PELIGRO – Para reducir el riesgo de descarga eléctrica:

1. Siempre desenchufe este accesorio de la toma de corriente eléctrica antes de limpiarlo o repararlo.

ADVERTENCIA: para reducir el riesgo de quemaduras, incendios, descargas eléctricas o lesiones a personas:

1. Desenchufe del tomacorriente antes de colocar o quitar partes.
2. Nunca opere este accesorio si tiene un cable o enchufe eléctrico dañado, si no funciona correctamente, o si el cable o el enchufe eléctrico se ha dañado o se ha caído al agua. Deje de usar este equipamiento y llame a un centro de servicio para que lo examinen y lo reparen.
3. Mantenga el cable eléctrico y el enchufe lejos de superficies calientes y otras fuentes de calor.
4. Para desconectar, gire todos los controles a la posición de apagado, luego retire el enchufe del tomacorriente.
5. Al operar, asegúrese de que el cable eléctrico no esté debajo de la base, las patas o el mecanismo de movimiento para evitar dañar el cable eléctrico o el enchufe.
6. No fuerce ni estire el cable eléctrico.
7. No utilizar cables de extensión o tomas de corriente.
8. Mantener fuera del alcance de los niños. Esto no es un juguete.
9. Enchúfelo directamente a una toma de corriente compatible.
10. No modifique el enchufe ni utilice adaptadores.

NOTE :

To ensure that the unit is levelled, assemble the unit on flat & soft surface. DO NOT tighten all the screws & bolts until the unit been adjust & level all the legs so that they do not wobble. Once adjusted then only tighten all the screws using Allen Key while making sure the unit remain level.