



ASSEMBLY INSTRUCTIONS





MODEL : 3378-24CU NAIL HEAD KYOTO STOOL





SKU# 43833789


Manufactured by (AXEL) for Rooms To Go

Version 1 09/2024

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts. Which may have come loose inside the carton during shipment. Identify and count all parts and compare with the hardware list as below :

Hardware List	No.	Description	Dimension	Picture	Qty
	①	JCBB M8	8 x P1.25 x 70mm [Length]		4 Pcs
		Spring Washer	M8 x 14mm		4 Pcs
		Flat Washer	M8 x 18mm		4 Pcs
	②	Allen Wrench	M4 x 95mm		1 Pc
	③	Pan Head Screw M4	4 x 38mm [Length]		8 Pcs
	④	Tools required (not included): PHILLIPS HEAD SCREW DRIVER			


Part List	No.	Description	Picture	Qty
	A	Seat		1 Pc
	B	Leg (L & R)		4 Pcs
	C	Side Stretcher		2 Pcs
	D	Front & Back Stretcher		2 Pcs



PARTS DETAILS

Hardware Pack Location(s) :

NAIL HEAD KYOTO STOOL, SKU# 43833789




Assembly step

STEP 1

Assemble LEG to SEAT FRAME together with SIDE STRETCHER as illustration shown.


DO NOT TIGHTEN THE SCREWS UNTIL FULLY SET UP.



STEP 2

Assemble LEG to SEAT FRAME together with FRONT & BACK STRETCHER as illustration shown.


DO NOT TIGHTEN THE SCREWS UNTIL FULLY SET UP.



STEP 3

Continue assemble SIDE STRETCHER to the LEG as illustration shown.


DO NOT TIGHTEN THE SCREWS UNTIL FULLY SET UP.



STEP 4

Fix the all the STRETCHER with screw as shown. as illustration shown.

FULLY TIGHTEN THE SCREWS AFTER ALL FINISH ASSEMBLE.



NOTE:

To ensure that stool is level, assemble the stool on flat & soft surface. **DO NOT** tighten all the screw & bolts until the stool been adjust & level all the legs so that they do not wobble. Once adjusted then only tighten all the screw using Allen Key while making sure that the unit remain level.