



ASSEMBLY INSTRUCTIONS







MODEL 3378-SE SERVER

SKU# 43933781

Manufactured by (AXEL) for Room To Go

Version 1 09/2024

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts. Which may have come loose inside the carton during shipment. Identify and count all parts and compare with the hardware list as below :


Hardware List	No.	Description	Dimension	Picture	Qty.
	①	Shelf Support	16 x 12mm / 18 x 12mm		8 PCS
	②	Screw	M3.5 x 12mm		8 PCS
	③	Furniture Tipping Restraint			1 SET
	④	Tools required (not included) : PHILLIPS HEAD SCREW DRIVER			
Part List	No.	Description	Picture		Qty.
	Ⓐ	Server			1 PC
	Ⓑ	Bottle Rack / Shelf Panel			2 PCS



PARTS DETAILS

Hardware Pack Location (s) :


Inside inner box of BOTTLE RACK /
SHELF PANEL
SKU# 43933781




Assembly step

STEP 1 **OPTIONAL - 1 for Bottle Rack version**

Assemble BOTTLE RACK to SERVER as illustration shown. DO NOT TIGHTEN THE SCREWS UNTIL FULLY SET UP.




We recommend that this unit is fixed to a suitable wall to prevent possible overbalancing.
We have included an Furniture Tipping Restraint hardware for this purpose.




Adjust the level to make sure it touch the floor

STEP 1 **OPTIONAL - 2 for Shelf Panel version**

Assemble SHELF PANEL to SERVER as illustration shown. DO NOT TIGHTEN THE SCREWS UNTIL FULLY SET UP.



We recommend that this unit is fixed to a suitable wall to prevent possible overbalancing.
We have included an Furniture Tipping Restraint hardware for this purpose.



Adjust the level to make sure it touch the floor