




***Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two person assembly is recommended in order to prevent personal injury and damaged parts.




Step 1: Attach the Front Leg (B) to the Seat Board (A) using the Allen Key (E) and Bolts (D).

Warning: Do not fully tighten the bolts at the start of assembly, otherwise the bolts will be stripped.



Step 2: Attach the Rear Leg (C) to the Seat Board (A) using the Allen Key (E) and Bolts (D).


PARTS LIST

NO.	A	B	C	D	E
DESC	Seat Board	Front Leg	Rear Leg	Bolt 1/4*45	Allen Key
PIC					
QTY	1pc	1pc	1pc	8pcs	1pc

Hardware Pack Locations:
CHAISE LOUNGESUN LOUNGE, 70561292

*****Caution:** Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two person assembly is recommended in order to prevent personal injury and damaged parts.

Step 3: Level the chaise and fully tighten all bolts using the Allen Key.



Warning: Do not fully tighten the bolts at the beginning of assembly, or the bolts may be stripped.