

ASSEMBLY INSTRUCTIONS


SHGP EASTLAKE 71 DINING TABLE SUPER WHITE


Manufactured for Rooms To Go

SKU 74061311


Thanks for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the Hardware List below

Caution: Loosely pre-assemble all the bolts first. Do not fully turn until all bolts are inserted into the proper holes.






Step 1: Place the Top(Part A) on a clean, soft surface as a blanket or carpet. Assemble the Leg(Part B) to the Top by Bolt(Part D) and Washer(Part E), tighten with Allen Key(Part Z).



Step 2: After tightening all bolts, your product is ready for use.



PARTS LIST PARTS LIST

NO.:	PIC	DESC	QTY	NO.:	F
А		Тор	1pc	D	M8
В		Leg	4 pcs	E	016*0
С		Umbrella Hole Cover	1pc	Z	

NO.:	PIC	DESC	QTY
D	NSX65	Bolt(M8*65)	8 pcs
E	016+08. 5+1. 5	Washer(Φ16*Φ8.5*1.5)	8 pcs
Z		Allen Key	1pc

Periodically check and make sure all bolts are fully tightened.