

Assembly Instructions

MONTARA DINING TABLE

SKU#74063125











Identify all parts packed in the carton against the parts list. Remove all protective materials. Place parts on a non-abrasive surface to avoid scratching.

Do Not Attempt Assembly If Any Parts Are Missing Or Damaged.

Warning: Please do not use acid or alkaline washing liquid to clean the product.

Assemble the product as shown below, step-by-step.


Part List

NO.	SKETCH	DESCRIPTION	QTY	NO.	SKETCH	DESCRIPTION	QTY
A		Leg	2	AA		Bolt (M6*25)	24
B		Support tube	2	BB		Steel Washer (Φ14*Φ6.5*1.5)	24
C		Table Top	1	CC		Bolt cap	24
D		Foot Glider	4	DD		Wrench	1
E		Plastic sleeve	1				
F		Umbrella hole cover	1				

JWUA GLA-40807-3631SKD
 Made in China


STEP 1

Hand tighten nut 3-4 revolutions only, do not tighten all the bolts and nuts.




STEP 2

Hand tighten nut 3-4 revolutions only, do not tighten all the bolts and nuts.




STEP 3

Need two people turn the table right side up. Adjust the pre-installed foot glider(D) at the end of each table leg until the table is level with the ground securely. Then put the inner sleeve (E) into the umbrella hole at the middle of the table, and cover the umbrella hole cover (F). Your table is ready to use.



STEP 4



***DO NOT OVER TIGHTEN**

***NO SOCKET DRIVERS**



***NO POWER TOOLS**

