




***Caution: Please read all instructions carefully before starting the assembly process. These parts are cumbersome and heavy. Therefore, two person assembly is recommended in order to prevent personal injury and damaged parts.

Step 1: Attach the Table Legs (B) to Table Top (A) using Allen Key (D) and Bolts (C).




Warning: Do not fully tighten the bolts at the beginning of assembly, or the bolts may be stripped.



Step 2: Level the table and fully tighten all bolts using the Allen Key.

PARTS LIST

NO.	A	B	C	D
DESC	Table Top	Table Leg	Bolt 1/4*45	Allen Key
PIC				
QTY	1pc	4pcs	8pcs	1pc

Hardware Pack Locations:
WAKEFIELD 71" RECT DINING TABLE, 74161298