

ASSEMBLY INSTRUCTIONS

ABOL CARINA 44X87/112 EXT DINING TABLE SKU 74300434

Thanks for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the Hardware List below

PARTS LIST

Item	Photo	Description	Qty
А		Table Top	1
В		Mid Leg	2
С		Table Leg	4
D		Short Leg Collecting Panel	2
Е	VANDARAM ON THE PROPERTY OF TH	Long Leg Collecting Panel	2
F		Connector	1
G		Umbrella Cover	1

Item	Photo	Description	Qty
Н	(4)	Bolt (5/16-18*1.18")	6
I		Bolt (5/16-18*1.57")	8
J		Bolt (5/16-18*1.77")	4
K	0	Flat Washer	18
L	0	Lock Washer	18
М	9	Nut	18
N	Θ	Nut Cap	18
0	5	Wrench	1

- 1. Place the table top (A) upside down on a non-abrasive flat surface. Align the holes in middle legs (B) and table legs (C) with the holes in the table top (A), Loosely secure the legs (B&C) to the table top (A) with the bolts (H) through flat washers (K), lock washers (L) and nuts (M). Do not tighten the bolts at this point.
- 2. Align the holes in legs (B) with the holes in the leg collecting panels (E), Loosely secure the connector (F) and the leg collecting panels (E) to the legs (B) with the bolts (J) through flat washers (K), lock washers (L) and nuts (M). Do not tighten the bolts at this point.
- 3. Align the holes in legs (C) with the holes in the leg collecting panels (D&E), Loosely secure the leg collecting panels (D&E) to the legs (C) with the bolts (I) through flat washers (K), lock washers (L) and nuts (M). Do not tighten the bolts at this point.
- 4. Check the alignment of all legs (B&C), and adjust if necessary. Once the alignment is correct and all bolts are in place, Properly tighten all the bolts (H&I&J) and nuts (M) using wrench (O). Cover the nuts (M) with nut covers (N). With the help of another person, carefully turn the table to the upright position.

Place umberlla cover (G) on table top (A). The table is ready for your enjoyment.



