

Manufactured for Rooms to Go

ZXFC	76012132	SIESTA KEY RD 30" BALCONY TABLE
ZXFC	76112134	SIESTA KEY RD 40" BALCONY TABLE
ZXFC	76412130	SIESTA KEY RD 30" BAR TABLE
ZXFC	76512132	SIESTA KEY RD 40" BAR TABLE

IMPORTANT: PLEASE READ COMPLETE INSTRUCTION SHEET PRIOR TO ASSEMBLY! Identify all parts packed in carton against the parts list. Remove all protective materials, place parts on a nonabrasive surface to avoid scratching. If any parts are missing or damaged, DO NOT attempt to assemble. Please contact our customer service center (Monday-Friday 9:00 a.m.-5:00 p.m. CST) at 1-877-931-7378 (fax: 952-746-0344), or e-mail: xinyue@xinyueinternational.com

Step 1

Take out table Top A on the soft surface, attach Table Leg B with Top A by Bolt 1/4"*40 G & Washer H, do not tighten completely.

Step 2

Take out Connect Ring1 C and Connect Ring2 D,attach Leg B with Connect Ring1 C and Connect Ring2 D by Bolt 1/4"*25 F & Washer H, use Wrench I, tight all bolts, put on PE Cap E.

Step 3

Turn over and clear the table, Put the umbrella hole cover. now your table is ready to use.

IMPORTANT:

- To avoid damage to your table: An umbrella base must be used at all times.
- If applicable, make sure the plastic umbrella safety ring is installed in the center of the table before you insert the umbrella pole through the table.
- Remove umbrella from the table when not in use or in the event of wind, rain, hail, sleet, snow or any other inclement weather.
- In storing patio furniture, do not stack anything on glass, stone or marble table tops.
- Before storing, drain all water that may have accumulated in or around table frame. If not drained properly, water can cause freeze damage.
- Cover furniture with outdoor furniture covers when not in use.
- For safety reasons, do not sit or stand on the table.

	ARTS LIST									
A	Table top		1	F	Bolt 1/4"-20*25mm		16			
В	Table leg		4	G	Bolt 1/4"-30*40mm		4			
С	Connect ring 1		1	Н	Washer		20			
D	Connect ring 2		1	ı	Wrench		1			
E	РЕ сар	0	20	J	Umbrella hole cover	0	1			

