





















ASSEMBLY INSTRUCTION

NO: M428

A	M8×57mm  x1	B	M8×25mm  x2	C	M8×60mm  x2	D	M8×40mm  x10	E	M6×45mm  x8	F	 x3
G	 x1	H	 x2	I	M8×22×2mm  x10	J	M6×12×1mm  x4	K	M6  x1		



Important Notes

*Keep all hardware parts out of reach of children!

*Tighten screws periodically! With the use of this product bolts and screws may become loose over time!

*Don't attempt to modify parts!