

ASSEMBLY INSTRUCTIONS

SKU# 97567

Before beginning

Unpack all parts and hardware to ensure you have all needed components for assembly.

Read this guide cover before beginning assembly.

Assemble this item on a soft surface such as carpet to protect finish.

Proper assembly of this item requires 2 people & 20 minutes to assemble.


Loosely thread all the bolts first. Once the item is assembled then completely tighten.

CARE INSTRUCTIONS

Wipe with a soft dry cloth. To protect finish, avoid the use of chemicals and household cleaners, Any liquid spilled on the table should be cleaned up immediately with a damp cloth.


TOP

A



BASE

B



HOW TO ASSEMBLY






STEP-1 Place the dining upside down on rug.

STEP -2 Insert allen bolt (C) with flat washer (D) then tighten with allen key (E).


STEP -3 Insert hexagonal bolt (F) with flat washer (D) then tighten with spanner (G).

STEP -4 Turn the dining upside top. Dining is ready to use.


Hardware & Tool Required:-

No.	Sketch	Description	Size	Qty.	Ext.
C		Allen bolt	0.78"x0.31"	5	1
D		Washer	1"x0.39"	6	1
E		Allen key	0.19"	1	0
F		Hexagonal Bolt	0.25"x0.31"	1	1
G		Spanner	0.47"/0.51"	1	0


STEP -1




STEP -2



STEP -3



STEP -4



Tip for leveling of product:
When the product rests on an uneven floor surface it will appear to be unbalanced to aid in levelling, try adjusting the levelers located on the bottom of each foot.

FINAL PRODUCT