

ASSEMBLY INSTRUCTIONS

SKU# 97569

Before beginning

Unpack all parts and hardware to ensure you have all needed components for assembly.

Read this guide cover before beginning assembly.

Assemble this item on a soft surface such as carpet to protect finish.

Proper assembly of this item requires 2 people & 20 minutes to assemble.

CARE INSTRUCTIONS

Wipe with a soft dry cloth. To protect finish, avoid the use of chemicals and household cleaners, Any liquid spilled on the table should be cleaned up immediately with a damp cloth.


TOP

A



BASE

B



HOW TO ASSEMBLY

STEP-1 Place the dining upside down on rug.


STEP -2 Insert allen bolt (C) with flat washer (D) then tighten with allen key (E).

STEP -3 Turn the dining upside top. Dining is ready to use.


Hardware & Tool Required:-

No.	Sketch	Description	Size	Qty.	Ext.
C		Allen bolt	0.62"X0.23"	4	1
D		Washer	0.70"X0.23"	4	1
E		Allen key	0.15"	1	0


STEP -1



STEP -2



STEP -3



FINAL PRODUCT