










ITEM NAME/NOM D'ITEM: GEORGES DINING CHAIR
ITEM #/NO. ITEM:109661

PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(3)	(4)
			<p>A  x4 (M6x25mm)</p> <p>B  x3 (M6x16mm)</p> <p>C  x4 (M6x16mm)</p> <p>D  x1 (M4)</p> <p>E  x1 (M5)</p>

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

I




E
A
C

3

2

II




C

1

B D

III



For missing parts or damaged parts, please call /
 Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866)-798-6663