

# ASSEMBLY INSTRUCTION



## SKU# 77205

**Before beginning**

- Unpack all parts and hardware to ensure you have all needed components for assembly.
- Read this guide cover before beginning assembly .
- Assemble this item on a soft surface such as carpet to protect finish.
- Proper assembly of this item requires 2 person & 20 minutes to assemble.

**CARE INSTRUCTIONS**

Wipe with a soft and dry cloth. To protect finish, avoid the use of chemicals and household cleaners. Any liquid in the table should be cleaned up immediately with a damp cloth.







**HOW TO ASSEMBLY**

STEP-1 Place the bench top upside on rug and match marking A with B respectively.

STEP-2 Insert allen bolt D with spring washer F and flat washer E then tighten with allen key C

STEP-3 Turn the bench down bench ready to use.

No.	Sketch	Description.	Size (IN)	Qty.	Ext.
C		ALLEN KEY	0.19"	1	0
D		ALLEN BOLT	0.31X1.57"	04	1
E		WASHER	0.35X1"	04	1
F		SPRING WASHER	0.35X0.5"	04	1


# STEP-1

Tip for leveling of product:  
When the product rests on an uneven floor surface  
it will appear to be unbalanced. To aid in leveling, try  
adjusting the levelers on the bottom of each foot.

Adjustable levelers





## Step - 2



Final

## Step - 3



Adjustable Levelers