

ASSEMBLY INSTRUCTION

SKU# 77232


Before beginning

- Unpack all parts and hardware to ensure you have all needed components for assembly.
- Read this guide cover before beginning assembly .
- Assemble this item on a soft surface such as carpet to protect finish.
- Proper assembly of this item requires 2 person & 20 minutes to assemble.


CARE INSTRUCTIONS

Wipe with a soft and dry cloth. To protect finish, avoid the use of chemicals and household cleaners. Any liquid in the table should be cleaned up immediately with a damp cloth.

A



B







HOW TO ASSEMBLY


STEP-1 Place the bench top upside on rug and match marking A with B respectively.

STEP-2 Insert allen bolt D with spring washer F and flat washer E then tighten with allen key C.


STEP-3.Turn the bench down ready to use.

No.	sketch	Description.	size(IN)	Qty.	Ext.
C		ALLEN KEY	0.19"		
D		ALLEN BOLT	0.31"X0.18"		
E		WASHER	0.35"X0.1"		
F		SPRING WASHER	0.35" X0.0.5"		


STEP-1




Tip for leveling of product:
When the product rests on an uneven floor surface
it will appear to be unbalanced. To aid in leveling, try
adjusting the levelers on the bottom of each foot.




STEP-2



STEP-3



STEP- 4



STEP- 5