Progressive®

ASSEMBLY INSTRUCTION

Item No: D422-95

Description: COUNTER HEIGHT TABLE SET



IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to
- Do not tighten all screws/bolts until all completely assembled.

STEP 2

- Keep all hardware parts out of reach of children!

 Tighten screws periodically! With the use of this product bolts and screw may become loose over time!
- Don't attempt to modify parts!

PARTS LIST - TABLE					
NO.	COMPONENT		QTY.		
1	TABLE TOP		1 PC		
2	TABLE LEG - Left		1 PC		
2.5	TABLE LEG - Right		1 PC		
3	CROSS BAR		1 PC		
4	USB PLUG		2 PCS		

HARDWARE LIST - TABLE				
NO.	COMPONENT		QTY.	
A	JCBC BOLT M6 x 40MM		14 PCS	
В	JCBC BOLT M6 x 50MM		4 PCS	
C	1/4" SPRING WASHER	©	18 PCS	
D	CB SCREW M4 x 32MM	()	4 PCS	
E	ALLEN KEY		1 PC	

PARTS LIST - STOOL				
NO.	COMPONENT		QTY.	
5	WOODEN SEAT		3 PCS	
6	STOOL LEG		12 PCS	
7	RING		3 PCS	

HARDWARE LIST - STOOL				
NO.	COMPONENT		QTY.	
F	JCBC BOLT M6 x 40MM		12 PCS	
G	JCBC BOLT M6 x 50MM		12 PCS	
Н	1/4" SPRING WASHER	©	24 PCS	
Ι	ALLEN KEY		1 PC	













