ITEM NO.: I302-58M / 58R / 58B TV STAND

Thank you for purchasing this quality product. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. Be sure to check all packing materials carefully for small parts may have come loose inside the carton during shipment, clarify and count all parts and compare with the parts list below. Do not tighten all screws / bolts until all completely assembled.

Parts List				
No.	Description	Q.ty		
1	Top Panel	1PC		
2	Bottom Panel	1PC		
3	Side Panel	2PCS		
4	Upright Panel	1PC		
5	Upright Rail	1PC		
6	Upper Rail	1PC		
7	Bottom Rail	1PC		
8	Support Leg	1PC		
9	Shelf	2PCS		
10	Back Panel	2PCS		
11	Left Front Leg	1PC		
12	Right Front Leg	1PC		
13	Left Rear Leg	1PC		
14	Right Rear Leg	1PC		


Hardware List					
No.	Description	Sketch	Size	Q.ty	
Α	Wood Dowels		M8x 30mm	24pcs	
В	Screws	<i>₹1111111111</i>	M4x 45mm	8pcs	
С	Cam Lock		D15mm x T10mm	22pcs	
D	Cam Bolts		M6 x 40mm	22pcs	
Е	Cam Hole Cover		D15mm	22pcs	
F	Shelf Holder	0	D5mm x 16mm	8pcs	

NOTE: YOU WILL ALSO NEED A SCREWDRIVER (NOT PROVIDED)

These parts are cumbersome and heavy. Therefore, two ople are recommended in order to prevent personal injury and insure the parts are not damaged during the assembly.

/\ Important Notes

- *Keep all hardware parts out of reach of children!
- *Tighten screws periodically! With the use of this product bolts and screws may become loose over time!
- *Don't attempt to modify parts!




Cleaning instruction: Clean using soft cloth


ITEM NO.: 1302-58M / 58R / 58B TV STAND

x 22

STEP 1:




STEP 2:




Cleaning instruction: Clean using soft cloth


ITEM NO.: I302-58M / 58R / 58B TV STAND

STEP 3:





STEP 4:




Cleaning instruction: Clean using soft cloth


ITEM NO.: I302-58M / 58R / 58B

TV STAND

STEP 5:




STEP 6:




Cleaning instruction: Clean using soft cloth

ITEM NO.: 1302-58M / 58R / 58B TV STAND

STEP 7:







Cleaning instruction: Clean using soft cloth

ITEM NO.: I302-58M / 58R / 58B TV STAND

STEP 9:




STEP 10:




Cleaning instruction: Clean using soft cloth

ITEM NO.: I302-58M / 58R / 58B TV STAND

STEP 11:



STEP 12:



Cleaning instruction: Clean using soft cloth

ITEM NO.: I302-58M / 58R / 58B TV STAND

