

ASSEMBLY INSTRUCTION


SKU# 97539

Before beginning

- Unpack all parts and hardware to ensure you have all needed components for assembly.
- Read this guide cover before beginning assembly .
- Assemble this item on a soft surface such as carpet to protect finish.
- Proper assembly of this item requires 2 person & 20 minutes to assemble.

CARE INSTRUCTIONS

Wipe with a soft and dry cloth. To protect finish, avoid the use of chemicals and household cleaners. Any liquid in the table should be cleaned up immediately with a damp cloth.






HOW TO ASSEMBLE

STEP-1 Place the end table top upside on rug and match marking A with A and B With B and C with C respectively.


STEP-2 Insert allen bolt E with spring washer F and then tighten with allen key D.

STEP-3 Turn the end table upside down, end table ready to use.


No.	Sketch	Description.	Size (IN)	Qty.	Ext.
D		ALLEN KEY	0.19"	1	0
E		ALLEN BOLT	0.31X0.62"	18	1
F		WASHER	0.35X1 "	18	1

STEP- 1

Tip for leveling of product:
When the product rests on an uneven floor surface
it will appear to be unbalanced. To aid in leveling, try
adjusting the levelers on the bottom of each foot.



STEP- 2



STEP- 3

FINAL

