



Assembly Instructions

8714333 END TABLE


**Product Issues? Please Call Us Before Contacting Your Retailer At
1-800-549-3300, email customerservice@mshome.com, or visit mshome.co
We can help with Assembly Issues, Part Requests, Damages, & All Other
Product Related Questions**




MSH-USA



10 min



Two People Required



Approximate
space required



Do not use power tools


Replacement Parts:

A - Table Top x 1


B - Legs x 4

C - Bottom Frame X 1

D - Foot x 6




1




Foot and Leg were screwed together for shipping purposes. Firstly unscrew the Foot and Leg.


2




3



4



5



Adjust leveler if needed to
level case on uneven floor

