


# ASSEMBLY INSTRUCTION




Item No: T400 - 11



Description: CHAIR SIDE TABLE WITH USB



### IMPORTANT NOTE :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials , including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children !
- Tighten screws periodically ! With the use of this product bolts and screw may become loose over time !
- Don't attempt to modify parts !

PARTS LIST		
NO.	COMPONENT	QTY.
1	Table Top With Panel Rack 	1 pc
2	Table Leg 	4 pcs
3	Shelf Panel 	2 pcs

HARDWARE LIST		
NO.	COMPONENT	QTY.
A	JCBC Bolt M6 x 50mm 	8 pcs
B	1/4" Spring Washer 	8 pcs
C	1/4" Flat Washer 	8 pcs
D	CB Screw M4 x 38mm 	8 pcs
E	Allen Key 	1 pc

## STEP 1

