








Thank you for purchasing this quality product. Be Sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

(Note : Loosely thread all screws / bolts first. Once the Item is assembled then completely tighten.)



PARTS LIST :				HARDWARE LIST :				
NO.	DESCRIPTION	SKETCH	QTY	NO.	DESCRIPTION	SKETCH	SIZE	QTY
A	MARBLE TOP		1	D	BOLT		1/4" x 5/8"	8+(1) extra
B	WOODEN LEG		1	E	ALLEN KEY		4 mm	1
C	WOODEN LEG		1	F	WASHER		1/2"	8+(1) extra

STEP : 1 Fix both wooden legs as shown in below picture with the help of allen bolt and allen key and tighten properly

STEP : 2 Fix wooden legs with marble base as shown in below picture with the help of bolt and allen key and tighten properly



Tip A: Sometimes the furniture will not balance because of an uneven floor surface it rests on. In that case, try adjusting the levelers found on the bottom of each foot to aid in correcting.



FINISH