




Assembly Instructions




Item No. 77228

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment. (Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten.)


PARTS LIST:

NO	Description	Sketch	Quantity
A	Top		1
B	Leg		2
C	Support		1


HARDWARE LIST:

NO	Sketch	Description	Size	Quantity
D		Bolt	Ø0.23" x 0.63"	10+1
E		Washer	Ø0.23" x 0.63"	8+1
F		Allen wrench	0.16"	1



STEP: 1



FINISH:



STEP: 2



ADJUSTABLE
LEVELER

Tip for Leveling of product :
When the product rests on an uneven floor surface it will appear to be unbalanced. To aid in leveling, try adjusting the Levelers on the bottom of each foot.

