

LAMP ASSEMBLY INSTRUCTIONS for ROOMS TO GO
VENDOR CODE # CAST SKU # 90120709 MODEL # 0270

Important Safety Instructions:

- For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other). If the plug does not fit securely into your outlet, do not force it-contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way.
- These instructions are provided for your safety. It is important that they are read carefully and completely before assembling the fixture.
- This fixture has been rated for up to **(1) 100-watt TYPE A standard bulb** (not included). To avoid the risk of fire, do not exceed the recommended wattage.

Warning:


- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the lamp and allow it to cool before replacing the light bulb.**
- Do not touch the bulb when the fixture is turned on. Do not look directly at the lit bulb.**
- Keep flammable materials away from lit bulb.**

Pre-assembly:

- Remove all parts and hardware from the box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

Parts enclosed:

- (1) Finial (A)**
- (1) Harp Top (B)**
- (1) Harp (C)**
- (2) Harp Caps (D)**
- (1) Socket (E)**
- (1) Saddle (F)**
- (1) Shade (G)**



Assembly Instructions:

1. Insert the harp (C) into the Saddle (F), and lower the two Harp caps (D) until they cover the two-pronged saddle.
2. Unscrew the finial (A) from the harp top (B). Place shade (G) over the assembled harp, making sure the top extends through the hole at the top of the shade.
3. Attach the finial (A) and tighten to secure the shade.
4. Insert a bulb – Max 100 Watt (Type A) Standard (not included) into the socket (E)

Care instructions:

- Clean with soft, dry cloth.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the lamp.

LAMP ASSEMBLY INSTRUCTIONS for ROOMS TO GO

VENDOR CODE # CAST

SKU # 90120709

MODEL # 0270

IMPORTANT SAFETY INSTRUCTIONS

WARNING!

To reduce the risk of fire, electrical shock or personal injury

Read all instructions before using this product

- To reduce the risk of electrical shock always turn off and unplug from the electrical outlet before cleaning or servicing.
- Never operate this lamp if it has a damaged electrical cord or plug
- If the electrical cord or plug is damaged or dropped into water stop using and contact an electrical professional
- Keep the electrical cord or plug away from heated surfaces or other heat sources
- When operating, ensure that the electrical the cord is not under the lamp base to avoid damage to the electrical cord or plug
- Do not strain or stretch the electrical cord
- Keep out of reach of children
- Plug directly into a compatible electrical socket
- Do not modify the plug or use any adapters.

INSTRUCCIONES DE SEGURIDAD

IMPORTANTES

¡ADVERTENCIA!

Para reducir el riesgo de incendio, descarga eléctrica, o lesiones personales

Lea todas las instrucciones antes de usar este producto.

- Para reducir el riesgo de descarga eléctrica siempre apague y desconecte de la red eléctrica tomacorriente antes de limpiar o dar servicio.
- Nunca opere esta lámpara si tiene un daño el cable eléctrico o enchufe.
- Si el cable eléctrico o el enchufe están dañados o si se cae al agua, deje de usarlo y comuníquese con un electricista profesional.
- Mantenga el cable eléctrico o el enchufe alejados de superficies calientes u otras fuentes de calor.
- Al operar, asegúrese de que el sistema eléctrico el cable no está debajo de la base de la lámpara para evitar daños al cable eléctrico o al enchufe.
- No fuerce ni estire el cable eléctrico.
- Mantener fuera del alcance de los niños.
- Conéctelo directamente a una toma de corriente compatible.
- No modifique el enchufe ni utilice ningún adaptador.