

# UTTERMOST

## ASSEMBLY INSTRUCTIONS

**STYLE#: 29991-1**

**Carefully unpack all Assembly parts from the carton.**

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Thread **Part A** into the **Base** by turning **Part A** clockwise to tighten until snug.
3. Thread **Part B** into **Part A** by turning **Part B** clockwise to tighten until snug.
4. Locate the **Harp** by pressing the ends of the Harp into the **Saddle** on the top of **Base**.
5. Place the **Shade** over the top end of the **Harp**. Secure by thread the **Finial** onto the **Harp**. Hand tighten until snug.
6. Install correct Bulbs referring to fixture markings and /or labels for maximum wattage. (Not Included)

### IMPORTANT SAFETY INSTRUCTIONS

This Floor lamp has a polarized plug ( one blade is wider than the other ) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

