IMPORTANT SAFETY and ASSEMBLY INSTRUCTIONS:

Model No: RTG30046-1-CD Rooms to Go SKU No: 90143125

CAUTION: These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.

Do not plug into wall outlet before assembly. Unplug when replacing the lamp bulb. This lamp is meant for indoor use. Dry locations only.

- 1. Carefully unpack all parts from carton, remove covering from parts and check that all parts are included as shown in the illustration.
- 2. Insert the harp (3) into the saddle of the socket (4).
- 3. Place the shade (5) onto the harp (3) and secure it with the finial (6).
- 4. Install the bulb (not included) into the socket (2).
- 5. Insert the plug into the wall outlet and turn on the switch and enjoy your new lamp.

Use Type A (E-26) 3-way 150-watt max bulb or LED Equivalent (not included).

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Care and Maintenance:

To clean, wipe with a soft dry cloth. Never use chemicals or abrasive cleaners

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.



VENDOR CODE: UTCI

	INSTRUCTIONS IMPORTANTES	INSTRUCCIONES
SAFETY INSTRUCTIONS	RELATIVES À LA SÉCURITÉ	IMPORTANTES DE SEGURIDAD
THIS PORTABLE LAMP HAS A POLARIZED PLUG	CETTE LAMPE PORTABLE EST ÉQUIPÉE D'UNE PRISE POLARISÉE	ESTA LÁMPARA PORTÁTIL TIENE UN ENCHUFE POLARIZADO
(ONE BLADE IS WIDER THAN THE OTHER) AS	(UNE LAME EST PLUS LARGE QUE L'AUTRE). II S'AGIT D'UNE	(UNA CLAVIJA ES MÁS ANCHA QUE LA OTRA). PARA
A SAFETY FEATURE TO REDUCE THE RISK OF	MESURE DE SÉCURITÉ VISANT À LIMITER LES RISQUES	REDUCIR EL PELIGRO DE CHOQUE ELECTRICO, EL
ELECTRIC SHOCK. THIS PLUG WILL FIT IN A	D'ÉLECTROCUTION. CETTE FICHE NE PEUT ÊTRE INSÉRÉE DANS	ENCHUFE SÓLO ENCAJARÁ EN UN TOMACORRIENTE
POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG	UNE PRISE POLARISÉE QUE DANS UN SEUL SENS. SI LA FICHE	POLARIZADO DE UNA SOLA MANERA. SI NO ENCAJA EN
DOES NOT FIT FULLY IN THE OUTLET, REVERSE	NE SE LOGE PAS COMPLETEMENT DANS LA PRISE, INVERSER	EL CORRECTAMENTE, INVIERTA EL ENCHUFE, SI AUN
THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN	SA POSITION SI ELLE NE SE LOGE TOUJOURS PSA DANS LA PRISE,	ASI NO ENCAJA, PONGASE EN CONTACTO CON UN
EXTENSION CORD UNLESS PLUG CAN BE FULLY	S'ADRESSER À UN ÉLECTRICIEN QUALIFIÉ. NE PAS UTILISER DE	ELECTRICISTA AUTORIZADO. NO UTILIZAR NUNCA CON UN CABLE DE EXTENSIÓN A MENOS QUE EL ENCHUFE PUEDA
INSERTED. DO NOT ALTER THE PLUG.	RALLONGE ÉLECTRIQUE À MOINS QUE LA FICHE PUISSE S'Y INSÉRER COMPLETEMENT. NE PAS MODIFIER LA PRISE.	INSERTARSE POR COMPLETO. NO MODIFIQUE EL ENCHUFE.