

Assembly Instructions

FGID 656-EGGCR

EGG SHELL CRACKLE TABLE LAMP

SKU# 90165690

Manufactured by FGID for Rooms To GO

Bill of Materials/Hardware

Step	Hardware	Qty
3	Harp	1
4	Shade	1
5	Finial	1

ASSEMBLY INSTRUCTIONS

Note: Before you begin, separate all parts and compare them to the illustration to ensure a complete assembly.

- 1 Slowly pull out the cord from bottom of lamp until the socket assembly rests against lamp.
- 2 Fasten socket assembly onto lamp body. Be careful not to twist the power cord.
- 3 Insert harp into saddle.
- 4 Put shade onto harp.
- 5 Screw finial onto harp to secure shade tightly.
- 6 Install light bulb into socket/ (bulb not included)


IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this product

- 1. This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature
- 2. These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture
- 3. This fixture has been rated for up to one (1) 150 watt maximum 3-way standard A19 light bulb (not included) To avoid the risk of fire do not exceed the recommended lamp wattage
- 4. Do not strain or stretch electrical cord
- 5. This lamp is meant for indoor use. Dry locations
- 6. Keep out of reach of children. This is not a toy
- 7. Save these instructions

WARNING:

- * To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.
- * Do not touch bulb when fixture is turned on. Do not look directly at the lit bulb.
- * Keep flammable materials away from lit bulb



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Hardware Pack Location - attached underneath the top carton flap