

VENDOR: DNGH ITEM NO.: HRT7689 SKU:90176693

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack parts from carton, remove covering from parts and check that all parts are included as shown in the illustration.
2. Screw the Socket (D) into the Body (E) while pulling cord through the base.
3. Insert the harp (C) into the saddle of the socket (D).
4. Place the shade (B) onto the harp (C) and secure it with the finial (A).
5. Install the bulb into the socket (D).
6. Insert the plug into the wall outlet and turn on the switch and enjoy your new lamp.
7. To clean, use a soft dry cloth only. Never use chemical or abrasive cleaners.

Use a 150W (Maximum) Incandescent A Type bulb.(Bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES A FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※ **PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**

※ **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

