

IMPORTANT SAFETY and Assembly Instructions

Model No: RTG27823-1-CD
Rooms to Go SKU No: 90192798

CAUTION: These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.

Do not plug into wall outlet before assembly. Unplug when replacing the lamp bulb. This lamp is meant for indoor use. Dry locations only.

Parts List:

- (A) Base
- (B) Socket Assembly and (C) Saddle of Socket
- (D) Harp
- (E) Shade
- (F) Finial

1. Carefully unpack and place all parts on a soft, smooth surface. Inventory all parts.
2. Thread the socket assembly (B) clockwise to body (A).
 Carefully pull excess cord through the lamp base during assembly.
3. Install Harp (D) into the saddle of socket (C).
4. Place shade (E) onto Harp (D)
5. Screw and tighten finial (F) clockwise to saddle of socket (C).




Use Type A 150 watt max bulb or LED Equivalent (not included).

IMPORTANT SAFETY INSTRUCTION:

This portable luminaire has a polarized plug (one blade is wider than the other) as a safety feature to reduce risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Do not attempt to defeat this safety feature.

Care and Maintenance:

To clean, wipe with a soft dry cloth.



IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

INSTRUCTIONS IMPORTANTES RELATIVES À LA SÉCURITÉ

CETTE LAMPE PORTABLE EST ÉQUIPÉE D'UNE PRISE POLARISÉE (UNE LAME EST PLUS LARGE QUE L'AUTRE). IL S'AGIT D'UNE MESURE DE SÉCURITÉ VISANT À LIMITER LES RISQUES D'ÉLECTROCUTION. CETTE FICHE NE PEUT ÊTRE INSÉRÉE DANS UNE PRISE POLARISÉE QUE DANS UN SEUL SENS. SI LA FICHE NE SE LOGE PAS COMPLÈTEMENT DANS LA PRISE, INVERSER SA POSITION. SI ELLE NE SE LOGE TOUJOURS PAS DANS LA PRISE, S'ADRESSER À UN ÉLECTRICIEN QUALIFIÉ. NE PAS UTILISER DE RALLONGE ÉLECTRIQUE À MOINS QUE LA FICHE PUISSE S'Y INSÉRER COMPLÈTEMENT. NE PAS MODIFIER LA PRISE.

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

ESTA LÁMPARA PORTÁTIL TIENE UN ENCHUFE POLARIZADO (UNA CLAVIJA ES MÁS ANCHA QUE LA OTRA). PARA REDUCIR EL PELIGRO DE CHOQUE ELÉCTRICO, EL ENCHUFE SÓLO ENCAJARÁ EN UN TOMACORRIENTE POLARIZADO DE UNA SOLA MANERA. SI NO ENCAJA EN ÉL CORRECTAMENTE, INVIERTA EL ENCHUFE. SI AUN ASÍ NO ENCAJA, PÓNGASE EN CONTACTO CON UN ELECTRICISTA AUTORIZADO. NO UTILIZAR NUNCA CON UN CABLE DE EXTENSIÓN A MENOS QUE EL ENCHUFE PUEDA INSERTARSE POR COMPLETO. NO MODIFIQUE EL ENCHUFE.