
ASSEMBLY INSTRUCTIONS FOR ELIZA FLOOR LAMP

Model # 2144-01/22



- 1.Screw bottom pole clockwise onto base.
- 2.Screw middle pole clockwise onto bottom pole.
- 3.Screw upper pole clockwise onto middle pole.
- 4.Screw lamp cup clockwise onto upper pole.
- 5.Socket ring comes pre-assembled to the socket. Before assembling the glass shade, please unscrew this socket ring. Set glass shade onto socket and tighten clockwise with socket ring to secure shade.
- 6. Install the bulb by screwing it into the socket

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (1) 150W