





Archer Floor Lamp

Assembly Instructions
Instrucciones De Asamblea
Instructions d'Assemblée

Part # LFL-ARCHER XX+XX

LFL-ARCHER-220201

PARTS



⚠ WARNING: LIGHTING

- Read all instructions carefully and completely before assembly and use. Retain for future reference.
- Keep plastic bags and small parts away from children.
- For residential (non-commercial) use only.
- Warning: Risk of fire; Use ___ watt bulb max.
- Electrocution hazard.
- DO NOT use if cord is frayed/damaged.
- Periodically check for loose hardware; retighten as necessary.
- DO NOT use product if any component becomes damaged.
- DO NOT use power tools to assemble OR overtighten hardware.
- DO NOT stand on product. Use only for intended purpose.
- Max weight limit 25 lbs.