


## ASSEMBLY INSTRUCTIONS MODEL NUMBER W26109-1

THANK YOU FOR PURCHASING THIS FLOOR LAMP.  
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

**CAUTION: DO NOT PLUG INTO WALL OUTLET  
BEFORE ASSEMBLY.**

1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
2. Place lamp body (A) on soft, smooth surface and thread tube (B) into Lamp Body (A).
3. Thread tube (C) into tube (B), carefully pulling excess cord through the bottom of Lamp body (A).
4. Thread tube (D) into tube (C), carefully pulling excess cord through the bottom of Lamp body (A).
5. Thread tube (E) into tube (D), carefully pulling excess cord through the bottom of Lamp body (A).
6. Stand lamp up. If it is not facing forward, unthread tube (B) from the Lamp Body (A) just a little. Once it is in the correct position; tighten tube (B) onto lamp base (A) with 2 piece screws (I).
7. Remove socket ring (H) from the lamp holder (F).
8. Place shade (G) onto lamp holder (F).
9. Tighten socket ring (H) onto lamp holder (F).

1 E26 Standard 100 Watt Max bulb required, not included



### IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter this plug.

### Care and Maintenance

To clean, wipe with a soft dry cloth.