





UTTERMOST

Illustration

STYLE NO. :22520



PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151
www.uttermost.com



UTTERMOST

ITEM NO: 22520

WARNING: BEFORE INSTALLING, make sure the electricity supply is shut off to avoid a possible electric shock.

Assembly Instructions

1. Carefully remove the parts and hardware from the carton.
2. Fasten the Universal bar onto the Outlet Box by using the Outlet Box Screw .
3. Install both ground wires in the Universal bar with the Green Ground Screw supplied.
4. Place the white wire, ribbed or tinted wire evenly against the white wire from the outlet box and place the black, smooth or un-tinted wire evenly against the black wire from the outlet box. (Connecting the Wires - See Figure 2)
5. Use the Mounting Screw secure the Universal bar and Lamp Body as through the Mounting hole, and screwed by Ball Nuts until tightly.
6. The metal ring of round crystal hangs on the hook of lamp body.
7. Install 60 Watt, Type A bulb (NOT INCLUDED) or Type T45 Edison bulb (INCLUDED) into the socket of the fixture.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151
www.uttermost.com