

UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 22283

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Carefully unpack all lamp parts from carton. We suggest a licensed electrician for all fixture installations.

1. Take the lamp carefully out of the Carton, and place on a flat surface.
2. Be sure power to the installation point is OFF.
3. Screw the Mounting Screws into the Universal Bar place the Lock Washers over the Mounting Screws and thread the Hex Nuts onto the Mounting Screws as shown Secure the position of the Mounting Screws by tightening the Hex Nuts against the Universal Bar. Secure the Universal Bar to the Outlet Box with Outlet Box Screws. (See Figure 1)
4. Secure the Universal Bar to the Outlet Box with Outlet Box Screws
5. Connect the wire as shown. (See Figure 2)
 - a. Connect the House Ground Wire to the Fixture Ground Wire, secure with wire nut.
 - b. Connect the House White (or Ribbed) Wire to the Fixture Supply Wire (White or Ribbed Side), secure with wire nut.
 - c. Connect the House Black (or Red) Wire to the Fixture Supply Wire (Black or Smooth Side), secure with wire nut.
 - d. Carefully stuff all of the connected wires into the Outlet Box.
6. Place the Canopy onto Outlet Box aligning 2 holes in the Canopy with 2 Mounting Screws threaded on the Universal Bar and secure it against wall with Balls
7. Install the correct Bulb (Not Included) into the Socket until snug.
8. Thread the beaded end of the Stem into the Coupling underside of the Socket. Hand tighten until snug.
9. Locate the Diffuser, the Rubber Washer and the Metal Washer over the end of the Stem and secure with the Hex Nut. Tighten until snug
10. Thread the Finial onto the end of the Stem and hand tighten until snug.

Your installation is completed now. Restore electricity.

