ITEM# 3435-01


BEFORE STARTING- SHUT OFF BREAKER AT MAIN DISCONNECT

Make sure all power is disconnected at existing fixture and that there are no live wires in the junction box.

Not all junction boxes include simple wiring .If you are unsure or have doubts of electrical connection, call an electrician for assembly . Remove all items from the packaging.


Step 1.

- (1) If would like for this lamp to be hardwired into your ceiling, carefully cut pre-attached plug and cord as shown and then discard the part of plug.
- (2) Insert end of cord into corresponding hole of canopy (E). Thread 8-shade cord(A) into the cord and also insert the cord into mounting plate (B) as shown.
- (3) Remove 2(K) screws from the canopy (E) and Bracket(B).
- (4) Pull the cord to match length and tighten tiny screw (H) by tool .




Step 3.

Twist both ground wire in your home and in mounting plate (B) to green screw (G). Cover the connected wires with wire nut (F)



Step 5.


Push up the canopy (E) to cover Bracket (B) properly and fasten with the 2 screws (K) separately to tighten.




PARTS DIAGRAM:

- (1) Bracket (B)
- (1) Canopy (E)
- (3) Screw (C)
- (4) Wire nut (F)
- (2) 8-shade cord (A)

Assembly Instructions (English)








Step 2.

Find your ground wire, hot wire and neutral wire in your junction box and pull them through the central round hole of bracket.


Fasten Bracket (B) into junction box with 2 screws (C) to tighten.



Attach the neutral fixture wire (N) from the pendant to the neutral wire in junction box (usually white). Attach the hot fixture wire (L) from the pendant to the hot wire in junction box (usually black). Cover the connected wires with wire nut (F) tighten each connection by turning clockwise.

Step 6.

Place shade (P) onto the socket(O), and tighten clockwise with socket ring(Q) to secure shade. Screw bulb(R) clockwise into socket (O) to tighten.



GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (1) 40 watt type A vintage bulb included.

